

NAISH

KITEBOARD
USER MANUAL



TABLE OF CONTENTS

RELEASE OF LIABILITY, CLAIM WAIVER AND ASSUMPTION OF RISK AGREEMENT	
RELEASES & AGREEMENTS.....	03
WARNING & SAFETY PRECAUTIONS.....	04
 BOARD ASSEMBLY	
Twin Tip Assembly.....	05
Setting Up Twin Tip Bindings & Fins.....	06
Surfboard Assembly.....	07
Setting Up Surfboard Fins.....	08
 WARRANTY POLICY	 09



RELEASES & AGREEMENTS

RELEASE OF LIABILITY, CLAIM WAIVER AND ASSUMPTION OF RISK AGREEMENT:

RELEASE AND WAIVER OF CLAIMS AGREEMENT

In consideration of your use of this product, you hereby agree to the following, to the fullest extent permitted by law:

To waive any and all claims that you have or may have in the future against Naish International, a division of Nalu Kai Incorporated, or any of its agents, resulting from use of this product and any of its components. To release Naish International, a division of Nalu Kai Incorporated, or any of its agents from any and all liability for any loss, damage, injury or expense that you or any users of this product may suffer, or that your next of kin may suffer, as a result of the use of this product, due to any cause whatsoever, including negligence or breach of contract on the part of Naish International, a division of Nalu Kai Incorporated, or any of its agents, in the design or manufacture of this product.

ARBITRATION

In further consideration of the sale to you of this product and any of its components, you hereby agree to submit to binding arbitration any and all claims, which you believe you may have against Naish International, a division of Nalu Kai Incorporated, or any of its agents, arising from the use of any of the Naish International/Nalu Kai Incorporated equipment. The arbitration shall be pursuant to the rules of the American Arbitration Association.

Arbitration shall be commenced within one (1) year from the date on which any alleged claim first arose. Further, the arbitration shall be held in Maui, Hawaii unless otherwise mutually agreed to by all parties. The submission to the American Arbitration Association shall be limited and the arbitration award may be enforced by any court of competent jurisdiction.

BINDING EFFECT OF AGREEMENT

In the event of your death or incapacity, this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, assigns and representatives.

ENTIRE AGREEMENT

In entering into this Agreement, you are not relying upon any oral or written representations other than what is set forth in this agreement and User's Guide.

BY INFLATING THE LEADING EDGE AND ASSEMBLING THIS PRODUCT, YOU ARE AGREEING TO:

1) be bound to the terms set forth below and 2) require anyone using this product to be bound by such terms. If you are unwilling to be bound by these terms, return this product (before use) for a full refund.

ASSUMPTION OF RISK

Use of this product and any of its components involves certain inherent risks, dangers and hazards, which can result in serious personal injury and death. In using this product you freely agree to assume and accept any and all known and unknown risks of injury while using this equipment. The risks inherent in the sport can be greatly reduced by abiding by the Warnings and Guidelines listed in this User's Guide and by using common sense.



WARNING AND SAFETY PRECAUTIONS

READ THE FOLLOWING POINTS BEFORE ASSEMBLING YOUR BOARD:

WARNING & SAFETY

- Kiteboarding is a dangerous sport.
- Always use extreme caution when using this product.
- Misuse of this product can cause serious injury or death.
- Never use this product unless you are in good physical health.
- Never use this product unless you are an experienced swimmer.
- Never act in a careless manner when using this product.
- You are responsible for your own safety and the safety of others around you when using this product.
- If you are under the age of 18, you must have your parents or legal guardian read these warnings and instructions.
- If you are under 18 years of the age, you must not use this product without proper guidance and supervision by your parents or legal guardian.
- Use of this product exposes the user to unexpected and unavoidable risks, dangers and hazards.
- Do not use this product if you are under the influence of alcohol, drugs or medications.
- Never use this product in thunderstorm and lightning conditions.
- Never use this product in offshore wind conditions.
- Never use this product in wind conditions that are above your ability level.
- Make sure you take lessons from a certified kiteboarding school before using this product on-the-water.
- Make sure you have been trained by a certified kiteboarding school to launch and land your kite before using this product in the water.
- Always have an experienced kiteboarder assist you with launching and landing your kite on land.
- Make sure you know on-the-water self-rescue techniques before using this product.
- Always wear a harness designed for kiteboarding.
- Always wear a helmet, gloves, shoes and protective eyewear when using this product.
- Always wear a Coast Guard approved personal flotation device when using this product in the water.
- Always observe local rules and regulations when using this product.
- Never attempt to fly your kite over other people, pets or any other obstructions.
- Make sure to always have a 100 meter semi-circle area downwind and on both sides of your flying position that is clear of people, animals, and other obstructions.



BOARD ASSEMBLY

TWIN TIP ASSEMBLY



- A) Deck
- B) Bottom
- C) Rails
- D) Fin Screw Holes
- E) Bindings Inserts
- F) Handle Inserts
- G) Bindings (sold separately)
- H) Handle
- I) Fins




BOARD ASSEMBLY

TWIN TIP ASSEMBLY

SETTING UP YOUR APEX BINDINGS

- 1) Place Apex bindings at appropriate stance width lining up the chanel with the binding insert holes on your board.
- 2) Use the screws provided with the plastic washer to attach the binding to the board.
- 3) Before tightening completely, adjust the stance angle of your left and right binding to your riding preference.
- 4) Once your desired angle is set, finish tightening both screws on each binding so your bindings are securely on your board.



- 5) Adjust your bindings to best fit your feet by adjusting the velcro straps on either side. Be sure both velcro straps are completely secure before using on water to avoid the bindings coming loose during your session.



SETTING UP YOUR FINS

If your board comes with our 4.5 cm asymmetrical fins, ensure your fins are on the correct side facing the proper direction using the reference image below.



BOARD ASSEMBLY

SURFBOARD ASSEMBLY



- A) Deck/Deck Pad
- B) Rail
- C) Nose
- D) Tail/Kick Pad
- E) Foot Strap Inserts (not on all boards)
- F) Fins (Sold Separately)
- G) Leash Plug



BOARD ASSEMBLY

SURFBOARD ASSEMBLY

SETTING UP YOUR FINS

- 1) Ensure your fins are in the correct position. Side fins on thruster, quad & twin set-ups should always be installed with the flat side facing inward towards the middle of the board. Center fins are symmetrically curved on either side.
- 2) Gently slide the rear fin tab into the fin box towards the tail.
- 3) Apply pressure on the front of the fin until the fin seats completely. Never force the fin if you feel resistance.
- 4) Use your Futures fin key to tighten the screw. Tighten until snug - do not overtighten.

*The image below shows a board with 5 fin boxes, allowing it to be set up as a quad, thruster or twin. In this case it has been set up as a thruster with two side fins and one center fin. On quad set-ups, the rear fins are typically smaller than the front two fins.



WARRANTY POLICY

READ THE FOLLOWING POINTS TO KEEP YOUR FOIL IN THE BEST SHAPE

STANDARD WARRANTY

Naish provides a 12-month warranty from the date of purchase against defects in materials and workmanship on all new Naish kites, boards (twin tips, surfboards, foilboards), foils, and control systems, unless applicable consumer law dictates a longer period, in which case the applicable legal period prevails. Accessories (such as lines, harnesses, safety gear) and apparel (such as wetsuits, rashguards, jackets) are provided with a 6-month warranty period from the date of purchase, unless applicable consumer law dictates a longer period, in which case the applicable legal period prevails.,

The warranty is valid only for the original purchaser that bought the product from an authorized Naish dealer or via Naish.com and applies to recreational use only.

WHAT IS COVERED

- Manufacturing defects in materials and workmanship.
- Failures under normal recreational use of the product.
- Products purchased new from an authorized Naish dealer.

WHAT IS NOT COVERED

- Normal Wear and Tear: general signs of use such as scratches, discoloration, or cosmetic marks.
- Accidental Damage: Damage caused by impact, crashes, sharp objects, incorrect landings, or abuse.
- Improper Use: Rigging or use with non-Naish products, neglect, or exposure to harmful conditions.
- Natural Causes: Storms, salt corrosion, UV damage, or other environmental factors.
- Alterations and Repairs: Any unauthorized modifications or repairs void the warranty.
- Commercial/Professional Use: Products used in schools, rental centers, or by professional athletes.
- Second-Hand/Demo Equipment: Used, demo, or test products sold "as is."

Important Notes

- Warranty coverage applies only to the original purchaser. B2B transactions are specifically excluded from this policy (see below the policy for B2B transactions).
- Warranty claims must be submitted at the original point of sale, being either an authorized Naish dealer or directly through Naish for products purchased at Naish.com.
- Keeping your original packaging may be required if damage occurred during transit.

If you have further questions on how to file a claim or about your gear issue, give us a call at (509) 493-0043 and our customer service team will be more than happy to help.

For details of Naish's full warranty policy and how to claim for warranty, please visit: <https://www.naish.com/pages/naish-warranty>





DESIGNED IN MAUI, HAWAII

